

FOR ISSUE TO (ALL SSE)

SHE ALERT

Genie Access Platforms

What happened?

A Safety Alert has been issued by Crossrail regarding Genie access platforms. Genie have issued two safety notices that require immediate attention. The first safety notice refers to Genie models S-100/S-105, S120/S-125 and S-100HD. The second safety notice refers to a greater number of Genie Models – GS3384: GS-3390, GS-4390 and GS-5390: GS8415-42323 to 42382, GS8416F-42383 to 45118, GS84F-45500 to 45528, GS9015-50213 to 51063, GS9016F-51064 to 52951, GS90F-53300 to 53508.



S100 Diesel Straight Boom Lift

What action is required?

- Identify whether you have one of the machines listed above.
- The first notice states that Genie have discovered that some machine serial number labels are printed with the incorrect 'Machine Unladen Weight' value. In some cases this is significantly different to what it should be and may result in the machine being operated on a surface that is not capable of supporting the machine weight.
- The second alert states that Genie has become aware that the System Relief Valve Pressure in some machines were not properly calibrated. Improper calibration of the System Relief Valve Pressure may cause component damage.
- Both notices require users/owners of the machines to take further action. The detailed requirements of the safety notices relating to each machine model are available via:
<http://www.genielift.co.uk/en/sales-and-support/bulletin-campaigns/index.htm>
- The notices provide some technical instructions which may require assistance from a suitably qualified person.

Communication by (✓)	LSG	✓	Notice board	✓	Tool-box talk	✓	Team brief	✓
Communication complete by (✓)	1 week	✓	2 weeks	-	1-month	-	2-months	-

Issued by: Richard Gough, Head of Safety, Health and Environment, Networks

Date of issue: 30/01/2018